YK400XGS

Arm length 400mm Maximum payload 5kg Note. Built-to-order product. Contact us for the delivery period.

Wall mount / inverse type

■ Ordering method

YK400XGS RCX340-4 **150**

W: Wall mount (same as per external view) U: Inverse wall mount

No entry: None
F: With tool flange
S: With hollow shaft

3L: 3.5m 5L: 5m 10L: 10m

Specify various controller setting items. RCX340 ▶ **P.566**

Note 1. When installing the robot, always follow the specifications.

Do not install the ceiling-mount robot upside down or do not install the inverse type robot to a ceiling Incorrect installation can cause trouble or malfunction.

			X-axis	Y-axis	Z-axis	R-axis
Axis	Arm length		250 mm	150 mm	150 mm	-
specifications Rotation and		le	+/-125 °	+/-144 °	_	+/-360 °
AC servo motor output			200 W	150 W	50 W	100 W
mechanism	Transmission	Motor to speed reducer	Direct-coupled			
	method	Speed reducer to output	Direct-coupled			
Repeatability Note 1		+/-0.0	1 mm	+/-0.01 mm	+/-0.004 °	
Maximum speed			6.1 m	n/sec	1.1 m/sec	1020 °/sec (wall mount 720 °/sec (inverse wall mount
Maximum payload			5 kg (Standard specification), 4 kg (Option specifications Note 4)			
Standard cycle time: with 2kg payload Note 2			0.49 sec			
R-axis tolerable moment of inertia Note 3			0.05 kgm ²			
User wiring			0.2 sq × 10 wires			
User tubing (Outer diameter)			ф 4 × 3			
Travel limit			1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
Robot cable length			Standard: 3.5 m Option: 5 m, 10 m			
Weight			20 kg			

Note 1. This is the value at a constant ambient temperature.

Note 2. When reciprocating 25mm horizontally and 300mm horizontally (with a 2kg payload in rough-positioning arch motion).

Note 3. The acceleration coefficient is set automatically in accordance with the tip weight and R-axis moment of inertia settings.

Note 4. Maximum payload of option specifications (with tool flange attached or with user wiring and tubing routed through spline shaft) is 4kg.

■ Controller							
Controller	Power capacity (VA)	Operation method					
RCX340	1000	Programming / I/O point trace / Remote command / Operation using RS-232C communication					

Note. The movement range can be limited by changing the position of The involentaring can be initiated by draining the position of Y axis mechanical stopper. (The movement range is set to the maximum at the time of shipment.)

See our robot manuals (installation manuals) for detailed

> Our robot manuals (installation manuals) can be downloaded from our website at the address below https://global.yamaha-motor.com/business/robot/





